

Wooden Furniture Guide

What causes wood cracking?

Here are some possible causes of cracking in solid wood furniture:

- **Environmental factors:** Solid wood furniture is very sensitive to changes in temperature and humidity. Drastic fluctuations in temperature and humidity, such as buildings, floor heating, heating and other factors, can lead to the expansion and contraction of wood, resulting in cracking.
- **Improper use:** If solid wood furniture is subjected to external force, such as collision, friction, etc., or bear too much weight, this may also lead to cracking.
- **Maintenance:** Solid wood furniture may also crack if it is not properly maintained after getting home, if it is placed in direct sunlight or in a humid environment.

How to care for your wooden furniture:

In order to prevent cracking of solid wood furniture, the following measures can be taken:

- **Keep the indoor humidity stable:** It is recommended to keep the indoor humidity between 40% and 60% to avoid the impact of excessive drying or humidity on solid wood furniture.
- **Avoid direct sunlight:** Solid wood furniture should try to avoid direct sunlight, so as not to damage the paint or varnish on the surface of the furniture.
- **Proper use and maintenance:** When using solid wood furniture, avoid collision, friction and other external forces, and ensure that the table does not support excessive weight. In addition, regular maintenance of solid wood furniture is recommended, such as the use of special solid wood furniture repair paste to fill and repair cracks.