

Copenhagen Dining Chair

How to Keep Your Acrylic Furniture in Good Condition

Regular Maintenance

Use a damp microfibre cloth to wipe down the furniture weekly. Consistent cleaning helps prevent dust and grime build-up, which could lead to scratches or marks on the surface.

Dust Regularly

When dusting acrylic furniture, opt for a soft, non-abrasive, lint-free cloth. Make sure there are no sharp objects on the cloth to prevent any damage while dusting.

Use Soap and Water

When your acrylic furniture starts looking cloudy, it's time for a deeper clean. Simply use a mixture of soap and water, with a microfibre cloth to effectively clean your acrylic furniture.

Avoid Ammonia Usage

Ammonia can be found in glass cleaner and can harm acrylic furniture. It is recommended to refrain from using ammoniabased solutions when cleaning acrylic furniture.

Commercial Cleaning Product

Start by dusting and cleaning the furniture surface to eliminate dirt. Apply the commercial cleaning product that is specially made for acrylic materials and buff the area with a separate clean microfibre cloth. Use a dry microfibre cloth to finish buffing the surface. Clean small sections of the furniture until it is completely clean.

Eliminate Scratches

Polishing kits effectively remove damage and scratches. Start by applying the revitalizing treatment to the clean damaged surface, then use firm back-and-forth strokes with a clean, soft cloth to polish it. Repeat this process until the scratches disappear.

Prevent Any Future Damages

To prevent potential damage in the future, along with regular cleaning and upkeep of acrylic furniture, it is recommended to take preventive measures. One effective way is to cover your acrylic furniture with a soft sheet or cloth when not in use. Additionally, ensure that the acrylic is shielded from UV rays and sudden temperature fluctuations, as these factors can reduce the material's longevity.